User's Manual

1. How can I remove a defect myself?

Do not repair the equipment yourself. Only authorized service point can carry out repairs. Unskilled repair can cause irreversible damage or void the warranty guaranteeing free of charge service. Moreover, unassisted repair can be dangerous!

2. Can I install/configure my equipment myself?

If, after reading the User's Manual you still have doubt concerning the installation or configuration of the equipment, consult an authorized point of sale where the equipment was purchased, and ask for help. Depending on the kind of the installation service, the service may be paid or free of charge. If you have any doubt - call our Hotline: 0 801 88 88 (between 9.00 AM - 6.00 PM) or send your enquiry by e-mail to horn@horn.pl

3. Do scratched or damaged disks influence the quality of sound and picture?

Please do not use damaged or non-original records. Dirty or scratched disks can adversely affect the quality of music or fluency of film picture. The kind of disks used depends on supported formats (for detailed information, see the product card).

4. Must the equipment be placed in a specifc place or can it be placed in any place?

Ensure that the ventilation opening remain uncovered at all times - this will prevent overheating the equipment and its switching off. It is best to provide 10 cm of free space on the sides and above the equipment.